

IT

SCAMBIATORE A PIASTRE PER CALDAIA STAND ALONE 35-45 KW

Questa istruzione è parte integrante del libretto dell'apparecchio sul quale viene installato l'accessorio.

A tale libretto si rimanda per le AVVERTENZE GENERALI e per le REGOLE FONDAMENTALI DI SICUREZZA.

⚠ Prima di effettuare qualsiasi operazione togliere l'alimentazione elettrica all'apparecchio.

⚠ Questo accessorio deve essere installato solo da personale professionalmente qualificato.

Il kit è composto da:

- 1 Scambiatore a piastre
- 2 Supporto scambiatore a piastre
- 3 Tubo caldaia valvola kit scambiatore
- 4 Tubo uscita scambiatore
- 5 Tubo inferiore scambiatore
- 6 Nipplo
- 7 Guarnizione 1" 1/2
- 8 Vite autofilettante Ø 6.3x13
- 9 Foglio istruzioni

Q.tà

- 1
- 1
- 1
- 1
- 1
- 2
- 5
- 2
- 1

EN

PLATE HEAT EXCHANGER FOR STAND ALONE BOILER 35-45 KW

These instructions are an integral part of the installer manual on which the accessory is installed.

See the manual for the GENERAL WARNINGS, GENERAL SAFETY DEVICES.

⚠ Before carrying out any operation, first disconnect the electric power supply to the boiler.

⚠ The accessory must be installed by professional qualified personnel.

The kit is composed by:

- 1 Plate heat exchanger
- 2 Plate exchanger support
- 3 Boiler pipe valve kit exchanger
- 4 Exchanger outlet pipe
- 5 Exchanger bottom pipe
- 6 Nipple
- 7 1"1/2 gasket
- 8 Self-tapping screw Ø 6.3x13
- 9 Instruction sheet

Q.ty

- 1
- 1
- 1
- 1
- 1
- 2
- 5
- 2
- 1

