

REAR FLUE HOLE
FORATURA SCARICO POSTERIORE

TEMPLATE POSITION FOR UPPER-FLUE
CAUTION...USE THE CORRECT FLUE BEND!

