

SUPPORT BRACKETS KIT


These instructions are an integral part of the booklet of the appliance on which the accessory has been installed. Please refer to the GENERAL SAFETY INFORMATION and PRECAUTIONS in this booklet.

KIT DESCRIPTION

The brackets code 4155606, allow the air heater to be supported when installed on a wall.

PACKAGE CONTENTS

Description	Q.ty
A Fixing plate	2
B Support brackets	2
C Screw M8 x 20	8
D Nut M8	8
E Flat washer $\varnothing$ 8	8
F Split washer $\varnothing$ 8	4
G Screw M6 x 20	4
H Flat washer $\varnothing$ 6	4
I Split washer $\varnothing$ 6	4
Instructions	1





The assembly should be carried out by qualified personnel


- Mark the fixing holes using the fixing plate **A** as a template depending on the type of installation and the air heater model

Model	P
New ACU 12M-13M	489
New ACU 22M-23M	539
New ACU 32M-33M	589
New ACU 42M-43M	639
New ACU 52M-53M	689
New ACU 62M-63M	739
New ACU 72T-73T	789
New ACU 82T-83T	1,139
New ACU 92T-93T	1,339



- Drill a hole in the wall



- Fit the brackets to the support plates as shown in the figure
- Fix the assembled bracket to the wall using fixing systems suitable for the weight of the appliance and the type of wall



- Position the air heater and fix it with the screws supplied.



- ⚠ We recommend using the thread locker liquid.
- ⚠ Make sure the wall is supporting the weight of the appliance.
- ⊘ It is forbidden to use the brackets as a support for persons.
- ⊘ It is forbidden to use the brackets for other appliances.
- ⚠ Use adequate personal protection equipment (gloves, etc.).

